



- Protects glass and reduces scratches with front alignment and protection at the corners
- Front alignment of IG units also facilitates easier and safer gas filling and fourth-corner closing
- Foldable front harp assembly makes for easier manual loading and unloading
- Works manually and with AutoRack1


Get solution recommendations  
and payback analysis for any  
IAS system for your operation

Ryan McHugh  
330.954.3070  
[ryan@optigas.com](mailto:ryan@optigas.com)



# AutoRack1™

Automatically rack and unrack from horizontal  
and vertical lines anywhere in your operation



Reduce labor and damage  
Increase safety






# Reallocate Cart Labor and Reduce Glass Handling Damage with AutoRack1

AutoRack1 indexes and advances full racks without delay

AutoRack1 indexes and inserts units

Feed racks into the accumulator

Discover your automatic racking payback at [optigas.com/autorack/](http://optigas.com/autorack/)



- Racks units without an operator
- Racks up to 2,000 units per 8-hour shift
- Works with vertical and horizontal lines
- Does not scratch or damage glass
- Can rack off most IG and tempering lines
- Works with Intercept®, Super Spacer®, Duralite® and other spacer systems



Racking from a horizontal line

Unit moved to vertical

Unit advances to cart loading

Unit loading on cart

